




# CLAVERRACK RURAL ELECTRIC COOPERATIVE, INC.

32750 ROUTE 6  
WYSOX, PENNSYLVANIA 18854  
www.claverack.com --- 1(800) 326-9799

## Solar Interconnection Specifications



1. AC side of the inverter to be connected to the load side of the disconnect switch.
2. The disconnect switch must be a visibly open and lockable switch.
3. Line side of net meter to be connected to grid.
4. Service panel is typically located inside the house.

\*\*Solar configuration will vary depending on equipment manufacturer and location of solar panels.

